


1



Using 2 people firmly grab the outer upper legs and simply open your arms outwards whilst lifting slightly (pending set-up surfaces, higher for uneven and lower for smooth). Walk backwards as far as your arms will allow and lower the frame to the ground.

2



Now grasp the “V” section of the scissor frame with both hands and gently lift and walk backwards continuing to open your arms outwards. Note: Stop this step once the centre pole has risen no more than 300mm for ease of canopy fitment.

3



Place your Altegra Gazebo canopy carefully over the frame making sure that it is evenly dispersed across the entire frame. Lay the slack of the canopy in the inside of the frame for now.

4



In all 4 corners bring the velcro sections of the frame and canopy together making sure the inner part of the canopy lines up neatly with the frame upper legs.

5



Importantly, find the centre piece of the canopy top and ensure that it is loosely placed on the centre pole top cap.



6



Re-grasp the “V” section of the frame with 2 hands and walk backwards until the frame is fully expanded making sure the canopy falls nicely into place in all sections.

7



Walk inside the frame, place one foot on the pull ring at the bottom of the leg so the legs do not slide up and lock the upper pin into place by placing your hands on the scissor frame and pushing the corner upwards.

Once you hear the pin click into place repeat this step on the remaining legs prior to setting leg heights.

8



On the inside of the canopy wrap the velcro straps around the frame and back onto the velcro to keep the canopy secured to the frame.

Repeat this step on all points of the canopy.

9



Pull the leg height pull ring and let the leg fall down naturally to the first height position on all legs, try not to stand on the foot plate and lift as it can put unnecessary pressure on the frame.

For the desired height feed the lower leg down to your preferred position.

10



Altegra recommends to raise the leg heights in unison to prevent unnecessary frame pressure. If doing one at a time evenly raise the unit to prevent unwarranted stress.

Once the first height of the leg position is achieved simply walk around and raise the heights to any of the 5 positions available. If on an uneven surface the leg heights can be uneven to have the Gazebo horizontally positioned.

Enjoy your Altegra Gazebo

* See optional tie down instructions for extra stability

